


# Cleaning Instructions

TSPC - Series and IS-Series



**Dear Customer,**  
**if you want to clean the case and the front panel of your TSPC or your Totem,**  
**please follow the below instructions:**

- Remove large debris of dust or loose dirt with a vacuum cleaner or a soft brush. Never use compressed air or wipe debris into the case openings.
- Wipe the front glass with a soft and fluff-free cloth applying only little pressure. To achieve better cleaning results, the cloth can be moistened with water or a glass cleaner but it should never be wet. This cloth should be used for the front glass only and not for other surfaces.
- Any sticky contamination of the glass surface can be soaked with a moist cloth and then be wiped off. Never scratch or scrape with hard objects.
- Clean the metal surfaces with a cloth exclusively used for this purpose as described above for the glass pane.
- Never spray the cleaning agent directly onto the glass or metal surface. This might cause spots or stains.
- Never use aggressive or abrasive cleansers.
- Never use flammable cleansers while the unit is in operation or connected to electric power.
- In case liquid of any kind has entered the inside of the unit, please call the technical person in charge so that the unit is separated from power supply and submitted to service.